Environmental Lights.com[™] 11235 West Bernardo Court, Suite 102 San Diego, CA 92127 888-880-1880 Fax: 707-281-0567 EnvironmentalLights.com

SLESA-UE7 Quick Start Guide

You will need to install Easy Stand Alone Pro (ESA Pro) or Easy Stand Alone 2 (ESA 2) software onto your computer in order to use the SLESA-UE7. Both ESA Pro and ESA2 are compatible with the SLESA-UE7 and will allow you to create DMX lighting shows. ESA 2 works well for simple programming and is easier to get started with. ESA Pro was designed for the SLESA-UE7 and provides more control, taking full advantage of its features. Install the software by inserting the included CD or download and run the .exe file from Nicolaudie.

SLESA-UE7 External Connections

- Ethernet Port used to connect the SLESA to a computer network. It allows you to use the SLESA remotely and to control many units with one computer.
- Micro SD Slot used to store scenes for stand-alone use.
- Mini USB Port used to connect directly to a computer and supply power when used in stand-alone mode.
- Dry Contacts –used to trigger specific scenes in stand-alone mode.
- 3-Pin DMX Out The 3-pin DMX connector outputs the 1st DMX universe.
- 5-Pin DMX Out The 5-pin DMX connector outputs the 2nd universe in stand-alone mode or the 2nd and 3rd universes in live mode.



Live Mode

- Connect the SLESA-UE7 to your computer before starting the software. You can connect the SLESA-UE7 via the included USB cable, which will also supply power. Alternatively, you can connect it to your network using the Ethernet port and power it using the included adapter. With either method you will be able to control 3 DMX universes.
- 2. Start the software after the SLESA is powered on and the startup menu will recognize a USB or Ethernet connected device, depending on how you choose to connect it.
- 3. Connect the SLESA to your DMX setup if you will be using your computer to control it.

Each version of the software works a little differently and has different capabilities. We recommend reading the detailed manual for the version you choose in order to fully take advantage of what each program can do. That being said, there are a few basic steps that will get you started. These are outlined below for ESA Pro and ESA 2 versions of the software.

ESA Pro Software

1. Add your DMX lighting by opening the "Add Fixtures" menu in the top left corner.



2. In the ScanLibrary section, open the "generic" folder and select "rgb" (for any pixel or standard RGB LEDs). Click "Patch" to add an RGB device to the DMX universe. You will need a separate RGB device for each pixel or RGB strip (after you add one, you can select it, press Ctrl+C, then hold Ctrl+V to fill in the entire universe). Click "OK" to accept.

canLibrary	2	Pat	tch																							B	9		h	3	P) (36) S
	^	1	DMX	uni	vers	e 1	DI	MX i	unīv	erse	2 2		DMX	(un	iver	se 3	X	0	-													
		1	mb 1	3	4	ab 2	6	7	mb 3	9	10	roh 4	12	13	rah S	15	18	rah B	18	19	rah 7	, 21	22	mh S	24	25	rah S	27	28	ab 10	30	31 mh
		33	34		38	37		39	40	1	42	43		45	48		48	49		51	52		54	55		57	58		60	61		63 64
par 36			rç	gb.12		rç	gb.13		n	gb.14		n	gb.15	1		gb.10	3		gb.1	5		rgb.1	8		rgb.1	9		rgb.20			gb.21	
		gb.22	2 68	67 r	gb.23	69	70 rg	b.24	72	73 1	gb.25	75	76 r	gb.26	3 78	79	gb.27	7 81	82	gb.2	84	85	rgb.2	9 87	88	rgb.2	9 90	91	gb.29	93	94 rg	jb.29
		97	ab 29	99	100	b 29	102	103	-6.29	105	106	ab 29	108	109	ab 25	111	112	ab 2	114	115	ab 2	117	118	mb 2	120	121	rah 2	123	124	ab 29	126	127 roh
🗊 rgba		129	130		132	133		135	136		138	139	12. 	141	142	-	144	145		147	148		150	151	leases	153	154		158	157		159 16
g rgbd			rş	gb.29		1	gb.29		n	gb.29			gb.29			gb.2	•		gb.2	•		rgb.2	9		rgb.2	9		rgb.29			gb.29	
g rgbw	7	gb.25	9 162	163 ŋ	gb.29	165	166 rg	jb.29	168	169 rj	gb.29	171	172	gb.28	9 174	175	gb.29	9 177	178	gb.2	9 180	181	rgb.2	9 183	184	rgb.2	9 188	187	gb.29	189	190 rg	19 15.29
scanner	3	193	ab 29	195	198	h 29	198	199	ab 29	201	202	ab 29	204	205	ab 2	207	208	ah 2	210	211	ob 2	213	214	rah 2	218	217	rah 2	219	220	ab 29	222	223 27
	2		90.20																		80.2			80.2			90.0					
www.		225	228	227	228	229	230	231	232	233	234	235	236	237	238	239	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255 25
bright		257	258	259	260	261	282	283	264	265	266	287	268	269	270	271	272	273	274	275	276	277	278	279	280	281	282	283	284	285	286	287 28
e bicite		289	290	291	292	293	294	295	296	297	298	299	300	301	302	303	304	305	306	307	308	309	310	311	312	313	314	315	316	317	318	319 32
e 🛅 ac lighting																							1.000	1000								
acd lighting	+	321	322	323	324	325	326	327	328	329	330	331	332	333	334	335	336	337	338	339	340	341	342	343	344	345	346	347	348	349	350	351 35
rgb		353	354	355	356	357	358	359	360	361	382	383	384	385	386	367	368	389	370	371	372	373	374	375	376	377	378	379	380	381	382	383 38
Mode:	*	385	386	387	388	389	390	391	392	393	394	395	396	397	398	399	400	401	402	403	404	405	408	407	408	409	410	411	412	413	414	415 41
DMX universe 1	•	417	418	419	420	421	422	423	424	425	426	427	428	429	430	431	432	433	434	435	438	437	438	439	440	441	442	443	444	445	448	447 44
First DMX channel: 88	•	449	450	451	452	453	454	455	458	457	458	459	460	461	462	463	464	485	466	467	468	469	470	471	472	473	474	475	476	477	478	479 48
Number of fixtures: 1	*	481	482	483	484	485	488	487	488	489	490	491	492	493	494	495	498	497	498	499	500	501	502	503	504	505	508	507	508	509	510	511 51

3. The devices will be added to the "groups" area in the top right corner. Use the tools in the "groups" window to change the orientation of the devices to better match your actual setup. Select the devices that you want to control, which could be all of them or a subset.

Groups										_				
18 18 18 18	881	00		80 0	80	2	And and a	勸	0000 4				C	C
Fixtures Rects														
Group 1														
	001	002	003	004	005	005	007	COS	009					
	010	011	012	013	014	015	016	017	018					
	019	020	072	077	022	074	075	075	077					
	028	029	030	031	032	033	034	035	036					
	037	038	039	040	041	042	043	044	045					
	045	047	048	049	050	051	052	053	054					
	055	056	057	058	059	050	061	062	063					
	064	065	066	067	068	069	070	071	072					

4. Click the "Add Scene" button to add a new scene and the selected devices will appear on the timeline. You can adjust duration, repetitions, etc. using the buttons in the scene window.

		Time								
	Scenes	2 0 ·	Ģ				_			
2	🗐 Name	🕑 Durati	C Loop	∩ Next	Port •	∫ Fade	Scene	Short	📢 Audio	Image
	Scene 1	0.00s	Always loop		None	1.005				
	Timeines	. Color (R	С П (6)		51 - T	10s		158		

5. Drag an effect (from the effects tab) on the left to the timeline. This will bring up the effect window where you can select effect types and adjust parameters. Hit the play button to have the effect run while you adjust settings (this will output to your lights if they are connected).



6. Press the Play button in the timeline section to play your new program. You can also click on the "Live" tab at the top for easy access to all of your scenes.

ESA2 Software

- 1. You can manually control your lighting by moving the DMX channel sliders at the bottom without any setup. This is a great way to verify that your lights are connected and the DMX addresses are set correctly.
- 2. For more functionality, open the "GENERIC" folder and select "rgb" (for any pixel or standard RGB LEDs). Click "Patch" to add an RGB device to the DMX universe. You will need a separate RGB device for each pixel, RGB strip or RGB module (you can select one, press Ctrl+C then hold Ctrl+V to add fixtures quickly). Click "OK" to accept.

ScanLibrary			P	atch																															
~																									C	6	3	C	T	×	C 88	= [00. TU		
Q.+				Unive	rse 1	+																													
 GENERIC 		1 10	jb.1	3	4 1	jb.2	6	7	rgb.3	19	10	rgb.4	12	13	rgb.5	15	16	rgb.6	18	19	rgb.7	21	22 1	gb.8	24	25	rgb.9	27	28.6	gb.10	30	317	gb.11		
😰 cmy				33	34 19	Ь.12	36	37.6	jb. 1	33	40.0	gb.1	1.42	43.	gb, 1	5 45	46	gb, 1	48	491	gb. 1	51	521	gb. 18	54	55 7	gb: 19	57	58.0	gb. 20	60	61 (gb.,21	63	64.0
moving	head			b.22	56	67.rg	b.23	69	701	gb.2	72	731	gb.2	5 75	75	rgb.2	76	29	gb.2	7.81	82 6	gb.28	84	651	gb. 29	87	58.7	gb.3(90	91.0	gb.31	93	94.7	gb, 32	96
🕑 par 36					b.33	93	10019	base	102	103	gb.3	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128
par 56				129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160
g par 64		-		161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191	192
🕑 rgba				193	194	195	196	197	198	199	200	201	202	203	204	205	206	207	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223	224
😰 rgbd				225	226	227	228	229	230	231	232	233	234	235	236	237	238	239	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255	256
🕼 rgbw				257	258	259	260	261	262	263	264	265	266	267	268	269	270	271	272	273	274	275	276	277	278	279	280	281	282	283	284	285	286	287	288
() () (hnenels)				289	290	291	292	293	294	295	296	297	298	299	300	301	302	303	304	305	306	307	308	309	310	311	312	313	314	315	316	317	318	319	320
rgo (3 channels)				321	322	323	324	325	326	327	328	329	330	331	332	333	334	335	336	337	338	339	340	341	342	343	344	345	346	347	348	349	350	351	352
DMX universe	Universe 1	v		353	354	355	356	357	358	359	360	361	362	363	364	365	366	367	368	369	370	371	372	373	374	375	376	377	378	379	380	381	382	383	384
First DMX channel	106	v		385	386	387	388	389	390	391	392	393	394	395	396	397	398	399	400	401	402	403	404	405	406	407	408	409	410	411	412	413	414	415	416
Number of fixtures	1	v		417	418	419	420	421	422	423	424	425	426	427	428	429	430	431	432	433	434	435	436	437	438	439	440	441	442	443	444	445	446	447	448
				449	450	451	452	453	454	455	456	457	458	459	460	461	462	463	464	465	466	467	468	469	470	471	472	473	474	475	476	477	478	479	480
Index number	36	* *		481	482	483	484	485	486	487	488	489	490	491	492	493	494	495	496	497	498	499	500	501	502	503	504	505	506	507	508	509	510	511	512
	Patch																																		

3. Click the "Scene Editor" button on the top menu to bring up the scene editor. On the left side you can arrange your lights and select which ones you want to control. On the right you can create groups of lights as well as set color and brightness using the color wheel.



4. Select the "Effects" tab in the editor and click on the "FX" button to bring up effects. Drag the effect window on the left over the lights that you want to apply the effect to.

Fixtures	Tools	
Q		
	Groups	
	Presets Effects	
	Image: Color matrix effects ↓ + + + + Image: Color matrix effects	
	Pixel effect Position effect	
00000	V Curve effect	
	Spiral	
	Padus -30	
	Arm Count O 001	
	Gradient O00	

5. Click on the "Editor" tab to save scenes and adjust duration, repetition and triggers.



6. Click on the "Live" tab to access your saved scenes, which appear as blue boxes. Click on any of them to run that saved scene.



Stand Alone Mode

Once you have created scenes, you can download them to the SLESA-UE7 and run them without a computer. Note that only 2 universes are available for each SLESA-UE7 in stand-alone mode. Doing this requires a micro SD memory card (128MB included). Scenes do not typically require much memory, just 1MB is sufficient for thousands of steps in a full DMX universe.

ESA Pro

- 1. Click on the Stand Alone tab.
- 2. Select the area and specific scenes on the left and drag them over to the memory blocks displayed on the device.
- 3. You can copy all scenes on a page by right clicking and selecting "Assign All Scenes"
- 4. Click "Write the interface memory" to complete the download.
- 5. With the SLESA-UE7 disconnected from the computer, use the buttons to cycle through scenes and pages of scenes.

<u>ESA 2</u>

- 1. Click on the Stand Alone tab (it only appears when you have a connected device).
- 2. Click write memory to write all current scenes to the device. You can uncheck specific scenes in the "Editor" tab to prevent them from being downloaded.
- 3. With the SLESA-UE7 disconnected from the computer, use the buttons to cycle through scenes and pages of scenes.

NOTE: Some SLESA-UE7 units purchased before September 2015 have had issues with their DMX output freezing after running in stand-alone mode for several hours. This can be fixed by updating the DMX timing with the Hardware Manager program. Hardware Manager can be downloaded under Special Files <u>here</u>.

Once the program is downloaded and installed:

- 1. Connect the SLESA-UE7 to the computer.
- 2. Open the Hardware Manager program.
- 3. Select the "DMX in/out" tab and choose standard DMX timing.
- 4. Click "Store Settings" to apply the changes.

Beginning in September 2015 all SLESA-UE7s will ship with these settings.