

# EasyWireless DMX Quick Start Guide

Part number: EZ-DMX-TX, EZ-  
DMX-RX

## EZ Wireless Transmitter Set up



1. Plug the EZ Wireless Transmitter into a DMX Controller.
2. Power the EZ Wireless Transmitter using the included 5V adapter.



3. Press the recessed Adjustment Button to change the grouping of the transmitter. The group will be indicated by the Group Indicator Light. All receivers with the same color Group Indicator Light will be controlled by the transmitter. The EasyWireless transmitter and receiver come with seven groups allowing for up to 7 separate transmitters in the same installation.

## EZ Wireless Receiver Set up



1. Plug the EZ Wireless Receiver into a DMX Decoder.
2. Power the EZ Wireless Receiver using the included 5V adapter.



3. Unscrew the end cap on the receiver to view the Group Indicator Light. Press the recessed Adjustment Button to change the grouping of the receiver. The group will be indicated by the Group Indicator Light. Reattach the end cap once the grouping has been selected.