



powered by **lumenradio**
CRMX Inside

CiNTENNA DMX WIRELESS SYSTEM

by **iINNOVATIVE DIMMERS**

Featuring the
Cintenna TX, Cintenna RX, Cintenna RX Battery
and the Cintenna AKS


Powered by **lumenradio**

With the Cintenna System,
you no longer have to rely on bulky
DMX cables.
Installation is simple,
and setup is as easy as pressing a button


CONTENTS

Reccomended Configurations.....	5
Cintenna Instructions.....	6
Battery Cintenna Instructions.....	7
AKS Instructions.....	8-9
Antenna Options.....	10
FCC Information.....	11
Warranty.....	12

RECOMMENDED CONFIGURATION USING THE AKS



RECOMMENDED CONFIGURATIONS USING THE CiNTENNA TX



CiNTENNA

INSTRUCTIONS

- Step 1:**
Plug your Cintenna RX into a DMX-compatible fixture.
- Step 2:**
Power it up using the included AC adapter or an optional accessory cable.
Supply can be anywhere between 5-30 Volts DC.
- Step 3:**
Briefly Press the LINK button on your Cintenna TX or any LumenRadio CRMX transmitter.
2.4ghz WDMX G2, G3, and G4 Transmitters will also transmit to the Cintenna.
The Cintenna RX is RDM capable when linked to a LumenRadio Nova FX RDM.

That's it!

The transmitter will relay all DMX commands to the receivers.
If your fixture has a DMX out, you can continue the signal through a DMX daisy chain.

When you're done:

The Cintenna will stay linked indefinitely until you tell it not to, even if you unplug it!
To unlink just one Cintenna RX, hold down its Link button until the link indicator light goes off.
To unlink everything, hold down the transmitter's button for 3 seconds.
Receivers must be powered ON to receive unlink signal.

CiNTENNA BATTERY POWERED

INSTRUCTIONS

- Step 1:**
Plug your Cintenna RX Battery into a DMX-compatible dimmer or optical splitter.
- Step 2:**
Press the Power button underneath the micro USB port to power on.
USB power can optionally remain connected for long-term operation or for simultaneous charging during use.
- Step 3:**
Press the LINK button on your AKS, Cintenna TX or any LumenRadio CRMX transmitter.
2.4ghz WDMX G2, G3, and G4 Transmitters will also transmit to the Cintenna.
-The Cintenna RX is RDM capable when linked to a LumenRadio Nova FX RDM-

That's it!

The transmitter will relay all DMX commands to the receivers.
If your fixture has a DMX out, you can continue the signal through a DMX daisy chain.

When you're done:

Turn the Cintenna RX Battery off by holding the Power button for 3 seconds.
The receiver will retain its link indefinitely until you unlink it, even if powered off!
To unlink just one Cintenna RX, hold down its Link button until the link indicator light goes off.
To unlink everything, hold down the transmitter's button.
Receivers must be powered ON to receive unlink signal.

Charging:

The 14 hour battery can be charged with the supplied USB adapter.
Lo-Batt light will illuminate when 20 minutes of operating power are remaining.
Charge light goes off when the battery is full.
Charge light illuminates briefly upon power up with a full charge.
The Cintenna can charge and operate simultaneously.

INNOVATIVE DIMMERS LIMITED WARRANTY

We warranty all workmanship and parts to be free of defect and to work as intended for the specific product's designed use for two years from the date of purchase. Accidents, deliberate breakage and/or misuse of the products voids the warranty.

We will repair or replace at our discretion parts or whole units in order to remedy issues with workmanship and/or functionality of the products provided the products were used for their intended purpose and in conditions suitable for electronic devices. The products we sell are not intended for use in wet climates and require cooling of the unit if the ambient temperature is above 85 degrees F.

All buyers understand that electronics involving control via DMX or WiFi are only as good as the system in which those products work. Since it is assumed that our products will be used in conjunction with DMX controls and/or products that we do not manufacture the buyer accepts responsibility for understanding and implementing the use of our products in the context of a larger lighting control system which may or may not include third party products and Innovative Dimmers products.

Since we have no control of the environments the products are used in we do not warranty the cosmetic finish, whether paint, vinyl or silk screen.

If the product has been modified by the buyer the warranty is void. If the buyer's product has been modified at Innovative Dimmers the warranty will be extended 2 years on the new parts and workmanship performed by Innovative Dimmers.

If Innovative Dimmers is at fault in a warranty issue we will cover the cost of shipping the products to and from the service location of our choosing provided we chose the method of shipping.

If we determine that the product has been exposed to wet conditions, has been damaged by using incorrect voltage or otherwise not cared for in an appropriate manner the warranty is void.

Innovative Dimmers is not liable for incidental or consequential damages associated with the use of this product. Rat Pac and Innovative Dimmers liability will not exceed the purchase value of the product.

Warranty claims must be accompanied with proof of purchase including date of purchase and must be made in writing and cannot be transferred or sold to any party or individual.

Innovative Dimmers 7508 Tyrone Ave. Van Nuys, 91405
support@innovativedimmers.com

