
# COLORIST™ POD **7Qa**

## **User Manual**



## ILUMINARC°

### **Edition Notes**

The Colorist<sup>TM</sup> Pod 7Qa User Manual Rev. 2 covers the description, safety precautions, installation, programming, operation, and maintenance of the Colorist<sup>TM</sup> Pod 7Qa. ILUMINARC® released this edition of the Colorist<sup>TM</sup> Pod 7Qa User Manual Rev. 2 in February 2015. Read the guide that shipped with the Colorist<sup>TM</sup> Pod 7Qa and this User Manual before installing, operating, or maintaining this product.

#### Trademarks

The ILUMINARC® logo, the ILUMINARC® name and all other trademarks in this document related to services or products by ILUMINARC® are trademarks owned or licensed by ILUMINARC®, its affiliates or subsidiaries. Any other product names, logos, brands, company names, trademarks featured or referred to within this document are the property of their respective trademark holders.

#### Manual Usage

ILUMINARC® authorizes its customers to download and print this manual for professional information purposes only. ILUMINARC® expressly prohibits the usage, copy, storage, distribution, modification, or printing of this manual or its content for any other purpose without its written consent.

#### **Document Printing**

For better results, print this document in color, on letter size paper (8.5 x 11 in), double-sided. If using A4 paper (210 x 297 mm), configure your printer to scale the content of this document to A4 paper.

#### Disclaimer

ILUMINARC® believes that the information contained in this manual is accurate in all respects. However, ILUMINARC® assumes no responsibility for any error or omissions in this document. ILUMINARC® reserves the right to revise this document and to make changes from time to time in the content without obligation of ILUMINARC® to notify any person or company of such revision or changes. ILUMINARC® may issue a revision of this manual or a new edition of it to incorporate such changes. This does not constitute in any way a commitment by ILUMINARC® to make such changes.

#### **Document Revision**

The Colorist<sup>TM</sup> Pod 7Qa User Manual Rev. 2 supersedes all previous versions of this manual. Discard any older versions of this manual and replace with this version. Go to <u>http://www.Iluminarc.com/</u> for the latest version.

#### **Copyright Notice**

The entire content of this document, except where applicable and unless otherwise noted, is solely owned by ILUMINARC®, a wholly owned trademark of Chauvet & Sons, Inc. © Copyright 2015 ILUMINARC®.

All rights reserved.

Electronically published by ILUMINARC® in the United States of America.

Author	Date	Editor	Date
D. Couppe	01/27/15	D. Couppe	4/24/15

### **Table of Contents**

1. Introduction	1
What Is In The Box	1
Unpacking Instructions	
Claims	
Text Conventions	
Safety Notes	
Personal Safety	
Mounting and Installation	
Power and Wiring	
Operation	
2. Product Description	3
Features	3
Product Overview	
Product Dimensions	
3. Installation	6
Mounting	6
Orientation	
Installation	6
Procedure	6
AC Power	
Power Consumption	7
AC Plug	7
Power Linking	
DMX Linking	
DMX Connection	8
IP65 DMX Cable Table	
DMX Personality	
DMX Controller	
4. Operation	10
Control Panel Description	
Control Options	
DMX Programming	
Static Colors	
Auto Play	
Custom Color	
Temperature	
Passcode	
Dimmer	
Menu Map	
DMX Values	

5. Technical Information	14
Product Maintenance	
Product Repairs	
Photometrics	
LED Disclaimer	
LED Life	
LED Binning	
Color Rendering Index (CRI) Return Procedure	
Return Procedure	
Contact Us	
6. Technical Specifications	



Critical installation,

configuration, or operation information. Failure to comply with this information may render the product partially or completely inoperative, damage third-party equipment, or cause harm to the user





Useful information.

### What Is In The Box

- Colorist<sup>™</sup> Pod 7Oa .
- IP65 Power Input/Output Cords with adapters
- IP65 Data Input/Output Cords with adapters
- Warranty Card
- Quick Reference Guide

### Unpacking Instructions

Immediately upon receiving a product from ILUMINARC®, carefully unpack the carton. Check the contents of the box to ensure that all parts are present and that they are in good condition.

#### Claims

The carrier is responsible for any damage incurred during shipping. Therefore, if the received merchandise appears to have been damaged during shipping, the customer must submit the damage report and any related claims to the carrier, not ILUMINARC®. The customer must submit the report upon receipt of the damaged merchandise. Failure to do so in a timely manner may invalidate the customer's claim with the carrier.

For other issues such as missing components or parts, damage not related to shipping, or concealed damage, the customer must make claims to ILUMINARC® within 7 days of receiving the merchandise.

### **Text Conventions**

Convention	nvention Meaning	
1–512	A range of values in the text	
50/60	A set of mutually exclusive values in the text	
<set></set>	A button on the product's control panel	
Settings	A product function or a menu option	
MENU > Settings	ettings A sequence of menu options	
1–10	<b>10</b> A range of menu values from which to choose in a menu	
Yes/No	A set of two mutually exclusive menu options in a menu	
ON	A unique value to enter or select in a menu	




used throughout this document refers to the USITT DMX512-A transmission protocol.

The term "DMX"



There are no user-serviceable

parts inside this product. Any reference to servicing you may find in this User Manual will only apply to properly certified ILUMINARC® technicians. Do not open the housing or attempt any repairs unless you are certified to do so.



applicable local codes and regulations for the proper installation of this product.



Keep this manual for future consultation. If

you sell this product to another user, make sure that they also receive this manual.

In the unlikely event that your Colorist<sup>™</sup> Pod

7Qa may require service, please contact **ILUMINARC®** Technical Support.



Please consult with an Iluminarc Sales

Representative on the suitableness of this product for your installation. Failure to follow these guidelines or the recommendations of the Iluminarc Sales Representative may result in the product warranty being rendered VOID and any repair cost being the sole responsibility of the buyer.

### **Safety Notes**

Please read all the following Safety Notes carefully because they include important information on how to install, use, and maintain this product safely.

#### Personal Safety

- Avoid direct eye exposure to the light source while the product is on.
- Always disconnect this product from its power source before servicing.
- Always connect this product to a grounded circuit to avoid the risk of electrocution.
- Do not touch this product's housing when operating because it may be very hot.

### Mounting and Installation

- This product is for outdoor use (IP65). All indoor and limited outdoor permanent installations.
  - Not for permanent outdoor installation in locations with extreme environmental conditions. This includes, but is not limited to:
    - Exposure to a marine/saline environment (within 3 miles of a saltwater body 0 of water).
    - Where the normal high or low temperatures of the location exceed the 0 temperature ranges in this manual.
    - When mounting outdoors, do not point the product straight down. 0
    - Locations that are prone to flooding or being buried in snow. 0
    - Other areas where the product will be subject to extreme radiation or caustic 0 substances.
- CAUTION: When transferring product from extreme temperature environments, (e.g. . cold truck to warm humid ballroom) condensation may form on the internal electronics of the product. To avoid causing a failure, allow product to fully acclimate to the surrounding environment before connecting it to power.
- Make sure there are no flammable materials close to this product while it is operating.
- When hanging this product, always secure it to a fastening device using a safety cable (not provided).

### Power and Wiring

- To eliminate unnecessary wear and improve its lifespan, during periods of non-use completely disconnect the product from power via breaker or by unplugging it.
- Always make sure that you are connecting this product to the proper voltage, as per the specifications in this manual or on the product's sticker.
- Never connect this product to a dimmer pack.
- Make sure that the power input cable is not cracked, crimped, or damaged.
- Never disconnect this product by pulling on the power input cable.

#### Operation

- The maximum ambient temperature range is -20 °F to 110 °F (-29 °C to 43 °C). Do not operate this product outside these temperatures.
- In case of a serious operating problem, stop using this product immediately!

### 2. Product Description


The Colorist<sup>™</sup> Pod 7Qa is an IP65-rated wash product that may be used to light a variety of both indoor and outdoor applications.

The Colorist<sup>TM</sup> Pod 7Qa consists of 7 quad-color RGBA 15 watt LEDs which can be controlled via the control panel or DMX control connections located on the back of the cast aluminum housing. The power connections are also located on the back of the product.


### Features

- · 4-, 6- or 10-channel RGBA quad-color LED wash product
- Operating personalities:
  - 4-channel: RGBA
  - 6-channel: RGBA, dimmer, strobe
  - 10-channel: RGBA, dimmer, color macro, strobe, auto, speed, dimmer profile
- · RGBA color mixing with or without DMX control
- 3 distinct dimming profiles
- Touch sensitive LED display with Passcode protection
- · Built-in automated programs via DMX

### **Product Overview**




**Rear View** 



**Front View** 

### **Product Dimensions**



Colorist<sup>™</sup> Pod 7Qa User Manual Rev. 2

### 3. Installation

### Mounting

Before mounting this product, read and follow the safety recommendations indicated in the Safety Notes.

#### Orientation

Always mount this product in a safe position, making sure there is adequate room for ventilation, configuration, and maintenance.

#### Installation


ILUMINARC® recommends following the general guidelines below when mounting the Colorist<sup>TM</sup> Pod 7Qa.

- When selecting an installation location, consider ease of access to the product for operation, programming adjustments and routine maintenance.
- Product aperture must not hang between 171° and 189° on the vertical axis in outdoor environments.
- Not for permanent outdoor installation in locations with extreme environmental conditions.
- Make sure the product's mounting location can support its weight. See the Technical Specifications for the weight requirement(s) of this product.


#### Procedure


The Colorist<sup>TM</sup> Pod 7Qa comes with an adjustable floor-mounting bracket that doubles as a hanging bracket to which you can attach a mounting clamp, using the M12 holes in the bottom. This bracket also serves as a floor stand or wall-mount support. You must supply your own clamps and make sure the clamps are capable of supporting the weight of this product. You must use one mounting point per product. Product aperture must not hang between 171° and 189° on the vertical axis in outdoor environments.

### Mounting Clamp



**Floor Mounting** 









outdoor installation in locations with extreme environmental conditions.

Not for permanent





### **JMINARC**



Always connect the Colorist™

Pod 7Qa to a protected circuit with an appropriate electrical ground to avoid the risk of electrocution or fire.



Never connect the Colorist<sup>™</sup>

Pod 7Qa to a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel serves only as a 0-100% switch.



Make sure to connect the Colorist<sup>™</sup> Pod 7Qa to a power line with

the proper voltage and frequency, as per the specifications in this manual or on the product's sticker.

### AC Power

The Colorist<sup>™</sup> Pod 7Qa has an auto-ranging power supply that works with an input voltage range of 100-240 VAC, 50/60 Hz.

Make sure that you are connecting this product to the proper voltage, as per the specifications in this User Manual or on the product's sticker.

### Power Consumption


To determine the power requirements for the Colorist<sup>TM</sup> Pod 7Qa, refer to the label affixed to the side of the product. You may also refer to the Technical Specifications. The listed current rating indicates the maximum current draw during normal operation.

#### AC Plug


The Colorist<sup>TM</sup> Pod 7Qa comes with an IP65 power input cord terminated with a proprietary IP65 connector and an IP65 to Edison power cord adapter. If the power cord adapter that came with your product has no plug or you need to change the Edison plug, use the table below to wire the new plug.

Connection	Wire (U.S.)	Screw Color (U.S.)	Wire (Europe)	IP65 Pin
AC Live	Black	Yellow or Brass	Brown	1
AC Neutral	White	Silver or Gray	Blue	2
AC Ground	Green/Yellow	Green	Green/Yellow	3


#### **IP65 Power Connector Pins**



Male




Female



### Power Linking

The Colorist<sup>TM</sup> Pod 7Qa supports power linking. You can power link up to 23 products at 120 VAC, 38 products at 208 VAC, or 42 products at 230 VAC. Never exceed these numbers. This product comes with a power input cord. This product does not require additional power linking cables; however, if longer power linking cables are needed, they can be purchased separately.




When connecting the Colorist™ Pod 7Qa to local power, it may be necessary to use the localto-IP65 adapters supplied with this product.






may result in deterioration of the digital DMX signal.



(from the first product/controller to the last product) to 300-455 m (985–1,500 ft).



When not using the Power Output. DMX Input or DMX Output connectors, you must seal the cable ends with the supplied caps.

### **DMX** Linking

You may link the Colorist<sup>TM</sup> Pod 7Qa to a DMX controller using a standard DMX serial connection. If using other DMX products compatible with the Colorist<sup>™</sup> Pod 7Qa, you can control each individually with a single DMX controller.

If you are not familiar with the DMX standard, or if you need information about the DMX cables needed to link the Colorist<sup>™</sup> Pod 7Qa to a DMX controller, you may download the "DMX Primer" from the **ILUMINARC®** website at http://www.iluminarc.com/reports/dmx-primer.


### **DMX** Connection

The Colorist<sup>™</sup> Pod 7Qa uses a regular DMX data connection for its DMX personalities: 4-CH, 6-CH, and 10CH.

### **IP65 DMX Cable Table**

Connection	DMX (U.S.)	DMX (Europe)	IP65 Pin
Ground	Shield	Shield	1
Data -	White	Blue	2
Data +	Red	Brown	3

#### **IP65 DMX Connector Pins**





Female

If you have not configured the DMX starting address and DMX personality for each product, they will all use their default values. This means that all products will operate in unison.

### **DMX Personality**


The Colorist<sup>TM</sup> Pod 7Qa uses the standard DMX data connection for its 3 DMX personalities as per the table below. Refer to the <u>Introduction</u> chapter for a brief description of these personalities. Refer to the <u>Operation</u> chapter to learn how to configure the Colorist<sup>TM</sup> Pod 7Qa to work in these personalities. The <u>DMX Values</u> section provides detailed information regarding the DMX personalities.

DMX Personality	DMX Address
4-CH	509
6-CH	507
10CH	503

### **DMX Controller**

The Colorist<sup>TM</sup> Pod 7Qa can work with a standard DMX controller. The channel assignments will depend on the chosen DMX personality (see the corresponding <u>Menu Map</u> section) and the DMX address assigned to each product (see the <u>Programming</u> section).


The figure below illustrates how to connect the DMX controller to the Colorist<sup>TM</sup> Pod 7Qa.



### 4. Operation

### **Control Panel Description**

Button	Function	
<menu></menu>	Exits from the current menu or function	
<enter></enter>	Enables the currently displayed menu or sets the currently selected value in to the current function	
<ul><li>Navigates upwards through the menu list and increases the numeric value when in a function</li></ul>		
<down></down>	Navigates downwards through the menu list and decreases the numeric value when in a function	



### **Control Options**

You can set the Colorist<sup>TM</sup> Pod 7Qa start address in the **001–512** DMX range. This allows for the control of up to 51 products in the 10-channel **10CH** personality.

### **DMX Programming**

Carry out all the programming procedures indicated below from the control panel. Refer to the <u>Menu Map</u> to learn how the menu options relate to each other.

Use **<ENTER>** and **<MENU>** to change levels in the Menu Map. Use **<UP>** and **<DOWN>** to select from among the Menu Map options.

- 1. From the Main Level select any DMX personality 4-CH, 6-CH, and 10CH.
- 2. Go to d and select a starting DMX address (1-512).

### **Static Colors**

- 1. Go to C--.
- 2. Select a color (C 1–15).

#### Auto Play



modified.

- 1. Go to **P--**.
- 2. Select an auto program (P 1–5).
- 3. Go to S--.
- 4. Select an auto program speed (S 1–100).

### **Custom Color**

- 1. Go to U--.
- 2. Select a color (**r**, **g**, **b**, or **A**).
- 3. Configure the color value (0–255).
- 4. Repeat steps 4 and 5 for the other colors.



The Passcode is a default setting and not customizable.

**DIM1** is the fastest dimming

curve and DIM3

is the slowest.

#### Temperature

This menu option allows you to see the temperature of the product while it is operating.

- 1. Go to **teMP**.
- 2. The products temperature is displayed XX (°C).

#### Passcode

When **PASS** is active, the product will ask you to enter the Passcode (**<UP>**, **<DOWN>**, **<UP>**, and **<DOWN>**) after 30 seconds of control panel inactivity or upon power up.

- 1. Go to PASS.
- 2. Select a setting (ON/OFF).

#### Dimmer

This setting gives the user three different options to simulate the dimming curve of an incandescent lighting product.

- 1. Go to **dIM**.
- 2. Select a dimming curve (OFF or dIM1–3).

#### OFF

· Linear RGBA and Master Dimmer

#### DIM1-3

Non-linear RGBA and Master Dimmer

### Menu Map

Main Level	Progra	mming Levels	Description	
4-CH				
6-СН	d	1–512	Selects DMX personality and sets the DMX starting address	
10CH				
		C 1	R (red)	
		C 2	G (green)	
		C 3	B (blue)	
		C 4	A (amber)	
		C 5	GB	
		C 6	RB	
		C 7	RG	
С		C 8	RGB	
	С 9		RA	
	C 10		GA	
	C 11		ВА	
	C 12		RGA	
	C 13		RBA	
	C 14		GBA	
	C 15		RGBA	
P	Р	1–5	Selects an auto program	
S	S	1–100	Selects the auto program speed (slow to fast)	
	r			
U	g	0–255	Combines red, green, blue, and amber to make a custom	
0	b	0-235	color (0–100%)	
	Α			
		OFF	Off	
dIM	dIM1		Dimmine medice feet (JIM1) to	
	dIM2		Dimming profiles fast ( <b>dIM1</b> ) to slow ( <b>dIM3</b> )	
	dIM3			
teMP	XX		Shows product temperature (°C)	
PASS		On	Turns the passcode on or off	
1 400	OFF		runs de passeode on or on	

### **DMX Values**

10CH	Channel	Function	Value	Percent/Setting
••••	1	Dimmer	000 <b>ó</b> 255	0–100%
	2	Red	000 <b>ó</b> 255	0–100%
	3	Green	000 <b>ó</b> 255	0-100%
	4	Blue	000 <b>ó</b> 255	0-100%
	5	Amber	000 <b>ó</b> 255	0-100%
			000 <b>ó</b> 010	No function
	6	Strobe	011 <b>ó</b> 255	Slow to fast
			000 <b>ó</b> 010	No function
			011 <b>ó</b> 030	R: 100% G: 0–100% B: 0
			031 <b>ó</b> 050	R: 100%–0 G: 100% B: 0
			051 <b>ó</b> 070	R: 0 G: 100% B: 0–100%
			071 <b>Ó</b> 090	R: 0 G: 100%–0 B: 100%
			091 <b>ó</b> 110	R: 0–100% G: 0 B: 100%
			111 <b>ó</b> 130	R: 100% G: 0 B: 100%–0
			131 <b>ó</b> 150	R: 100% G: 0–100% B: 0–100%
			151 <b>ó</b> 170	R: 100%–0 G: 100%–0 B: 100%
	_	Color Macro + White	171 <b>ó</b> 200	RGBA: 100%
	7	Balance	201 <b>ó</b> 205	White 1
			206 <b>ó</b> 210	White 2
			211 <b>ó</b> 215	White 3
			216 <b>ó</b> 220	White 4
			221 <b>ó</b> 225	White 5
			226 <b>ó</b> 230	White 6 White 7
			231 Ó 235 236 Ó 240	White 8
			230 <b>O</b> 240 241 <b>O</b> 245	White 9
			241 <b>O</b> 243 246 <b>O</b> 250	White 10
			251 <b>ó</b> 255	White 11
			000 <b>ó</b> 051	No function
			052 <b>Ó</b> 101	Auto Program 1
			102 <b>ó</b> 152	Auto Program 2
	8	Auto Programs	153 <b>Ó</b> 203	Auto Program 3
			204 <b>ó</b> 254	Auto Program 4
			255	Auto Program 5
	9	Auto Speed	000 <b>ó</b> 255	Auto program speed (slow to fast)
			000 <b>ó</b> 051	Preset dimmer speed from display menu
			052 <b>ó</b> 101	Dimmer profile off (linear dimmer)
	10	Dimming Profiles	102 <b>ó</b> 152	Nonlinear dimming profile 1 (fastest)
		_	153 <b>ó</b> 203	Nonlinear dimming profile 2
			204 <b>ó</b> 255	Nonlinear dimming profile 3 (slowest)
	•			
6-CH	Channel	Function	Value	Percent/Setting
		Dimmer	000 <b>ó</b> 255	0-100%
	2	Red	000 <b>ó</b> 255	0–100%
	3	Green	000 <b>ó</b> 255	0–100%
	4	Blue	000 <b>ó</b> 255	0–100%
	5	Amber	000 <b>ó</b> 255	0–100%
	6	Strobe	000 <b>Ó</b> 010	No function
	U	511 000	011 <b>ó</b> 255	Slow to fast
		E	Value	
4-CH	Channel	Function		Percent/Setting
	1			

СН	Channel	Function	Value	Percent/Setting
	1	Red	000 <b>ó</b> 255	0–100%
	2	Green	000 <b>ó</b> 255	0–100%
	3	Blue	000 <b>ó</b> 255	0–100%
	4	Amber	000 <b>ó</b> 255	0–100%

### 5. Technical Information

### **Product Maintenance**

To maintain optimum performance and minimize wear, clean the products frequently. Usage and environment are contributing factors in determining the cleaning frequency. As a general guideline, products should be cleaned at least twice a month. Dust build-up reduces light output, performance, and can cause overheating. This can lead to reduced light source life. For products containing external optical lenses, clean them periodically to optimize light output. The cleaning frequency depends on the environment in which the product operates. Damp, smoky, or particularly dirty surrounding can cause greater accumulation of dirt on the product's optics, requiring more frequent cleaning. To clean a product:

- 1. Unplug the product from power.
- 2. Wait until the product is at room temperature.
- 3. Use a vacuum (or dry compressed air) and a soft brush to remove dust collected on the external vents and reachable internal components.
- 4. Clean all external glass optics and glass surfaces with a mild solution of glass cleaner or isopropyl alcohol, and a soft, lint-free cotton cloth or lens-cleaning tissue.
- 5. Clean all plastic surfaces, including LED lenses, with mild soapy water and a soft, lint-free cotton cloth or a lens-cleaning tissue.
- 6. Apply the solution directly to the cloth or tissue and wipe any dirt and grime to the outside edge of the lens.
- 7. Gently polish the external glass surfaces until they are free of haze and lint.


### **Product Repairs**

ILUMINARC® strongly advises you against attempting any repairs to this product unless you are an authorized ILUMINARC® technician.

Always dry the external optics and glass surfaces carefully after cleaning them.



### **Photometrics**



### LED Disclaimer

### LED Life

ILUMINARC® rates LED lifetime based on lumen depreciation of 70% of the original output, with data provided by the manufacturer of the LED. Data from the manufacturer of the LED are not independently verified or measured by ILUMINARC®. When the product is operating in optimal environmental conditions, the LED lifetime is rated to be 50,000 to 70,000 hours by the LED manufacturer.

### LED Binning

LED manufacturers sort LEDs into "bins," based on variances in color, output intensity, and the frequency at which the semiconductor operates. ILUMINARC® strives to hold its LED manufacturers to the highest standards of binning to optimize consistency in output from product to product. However, the availability of a single bin cannot be guaranteed. With that in mind, ILUMINARC® has developed a rigorous control system to seek the best-achievable consistency in color and output.

### **Color Rendering Index (CRI)**

CRI is an industry standard method to compare properties of different types of light sources. There are known limitations and inconsistencies related to CRI. Results may vary depending on the environmental factors involved. For this reason, the U.S. Department of Energy (DOE) states that CRI should be considered as one point of reference among others in evaluating white LED products and systems.

The following is an excerpt of recommendations from the DOE:

- 1. Identify the visual tasks to be performed under the light source. If color fidelity under different light sources is critically important (for example, in a space where color or fabric comparisons are made under both daylight and electric lighting), CRI values may be a useful metric for rating LED products.
- 2. CRI may be compared only for light sources of equal correlated color temperature. This applies to all light sources, not only to LEDs. Also, differences in CRI values of less than five points are not significant, e.g., light sources with 80 and 84 CRI are essentially the same.
- 3. If color appearance is more important than color fidelity, do not exclude white light LEDs solely on the basis of relatively low CRI values. Some LED products with CRIs as low as 25 still produce visually pleasing white light.
- 4. Evaluate LED systems in person and, if possible, on-site when color fidelity or color appearance are important issues.

Source: DOE publication: PNNL-SA-56891, January 2008.

ILUMINARC® reserves the right to use its own

discretion to repair or replace returned product(s).



## Always keep the original box and all packaging

material as you will need those to ship the product back to ILUMINARC®.

### **Return Procedure**

You must send the merchandise prepaid, in the original box, and with its original packing and accessories. ILUMINARC® will not issue call tags.

Call ILUMINARC® and request a Return Merchandise Authorization Number (RMA #) before shipping the product. Be prepared to provide the model number, serial number, and a brief description of the cause for the return.

The user must clearly label the package with an RMA #. ILUMINARC® will refuse any product returned without an RMA #. DO NOT write the RMA # directly on the box. Instead, write it on a properly affixed label.

Once you receive the RMA #, please include the following information on a piece of paper inside the box:

- Your name
- Your address
- · Your phone number
- The RMA #
- A brief description of the problem

Be sure to pack the product properly. Any shipping damage resulting from inadequate packaging will be the customer's responsibility. Proper FedEx packing or double-boxing are recommended.

### **Contact Us**

#### WORLD HEADQUARTERS - ILUMINARC®

#### General Information

Address:	5200 NW 108th Avenue
	Sunrise, FL 33351
Voice:	(954) 923-3680
Fax:	(800) 544-4898

## Technical SupportVoice:(800) 762-1074Email:support@iluminarc.com

World Wide Web www.iluminarc.com

UNITED KINGDOM AND IRELAND - Chauvet Europe Ltd.

#### **General Information**

Address: Unit 1C Brookhill Road Industrial Estate Pinxton, Nottingham, UK NG16 6NT Voice: +44 (0)1773 511115 Fax: +44 (0)1773 511110

#### MEXICO - Chauvet Mexico

#### **General Information**

Address: Av. Santa Ana 30 Parque Industrial Lerma Lerma, Mexico C.P. 52000 Voice: +52 (728) 285-5000

CHAUVET EUROPE - Chauvet Europe BVBA

#### **General Information**

Address: Stokstraat 18 9770 Kruishoutem Belgium Voice: +32 9 388 93 97 Technical Support Email: uktech@

mail: <u>uktech@iluminarc.com</u>

World Wide Web www.chauvetlighting.co.uk

#### **Technical Support**

Email: servicio@iluminarc.com.mx

World Wide Web www.chauvet.com.mx

#### **Technical Support**

Email: <u>Eutech@chauvetlighting.eu</u>

World Wide Web www.chauvetlighting.eu

Outside the U.S., United Kingdom, Ireland, Mexico, or Benelux, contact the dealer of record. Follow their instructions to request support or to return a product. Visit our website for contact details.

### 6. Technical Specifications

Dimensions and Weight	Length		Width	Height		Weight	
-	10.2 in (260 mm) 5.1		in (130 mm) 10.4 in (265		mm) 10.8 lb (4.9 kg)		
	Note: Dim	ensions	ns and Weight are rounded to the nea			Ũ	
Electrical	Power Supply Type Switching (internal)		Range		Voltage Selection		
			100–240 VAC, 50/60 Hz		Auto-ranging		
	Parameter		120 V, 60 Hz		230 V, 50 Hz		
_	Consumption		52 W (0.44 A)		51 W (0.24 A)		
	Power I/O		Input		Output		
_	Connectors		IP65 Input power		IP65 Output power		
	Cord plug		Edison		N/A		
Light Source	Туре		Power		Lifespan		
	LED		15 W		50,000 hours		
	Color		Quantity		Current		
_	Quad-color RGBA		7		985 mA		
<b>Photometrics</b>	Parameter		Standard Optics				
_	Lumens		1,176				
_	Efficacy		22.9 lm/W				
_	Illuminance @ 5 m		880 lux				
_	Beam angle		16°				
	Field angle		27°				
Thermal	Max. External Temperature		Cooling System				
	110 °F (43 °C)		Conve	ection			
DMX	I/O Connectors		Connector Type		Channel Range		
	Proprietary IP65 3-p	oin	IP	65		4, 6 or 10	
Ordering	Product Name		Item Code		UPC Code		
	Colorist <sup>™</sup> Pod 7Q	а	0363	0839		781462211875	
			UL 15	73		RoHS	
	(MET)® CSA C22.2 No. 166						
			-				
			<b>US</b> E1130	193		∕ <b>⊢</b> ®∖	

## ILUMINARC<sup>®</sup>